

Piemonte Wall Sconce

THECARGOODS.COM

SUPPORT@THECARGOODS.COM

- 1: Fix the hanging board to the wall
- 2: Connect the lamp wires to the reserved wires
- 3: Tighten the nut to secure the lamp body
- 4: Installing bulb
- 5: Buckle glass

