


LED Bedroom Art Deco

THECARGOODS.COM
SUPPORT@THECARGOODS.COM

- 1: Install the lamp body
- 2: Connect the lamp wires to the reserved wires
- 3: Fix to the wall with screws



Installation instructions:

1. All L live wires of the light arm lead are connected to the main L live wire, and all N zero wires of the light arm lead are connected
2. Clamp with a wiring cap, tighten the connection and strengthen the insulation with a heat shrink tube.
3. Connect and lock the main ground wire to a separate grounding device on the lamp body.
4. All LED light sources are connected in series (excluding high-voltage LEDs).

6. Connecting incorrectly can lead to no lights, short circuits flickering, or burning.