

Arc Glow Floor Lamp


THECARGOODS.COM

SUPPORT@THECARGOODS.COM

Take all the accessories out of the packaging first

Install lampshade and bulb

The plug is plugged into the socket and the electricity is turned on



The upper part of the lamp body can be rotated